



Environmental Sample Processor Contextual Sensors

5/22/14 Brent Roman brent@mbari.org



Supported Instruments

- **Can** => internal environmental sensors within ESP core's housing
 - Temperature, humidity, pressure, battery voltage, amperage
 - Updates every 10 minutes as long as ESP application runs
- **CTD** => Seabird SBE 16plus V2 interfaced via RS-232 sensor 1
 - Temperature, pressure, conductivity, plus *optional...*
 - Fluorometer, Transmissometer, Oxygen Sensor (1 of 2 types)
- **ISUS** => one of two types interfaced via RS-232 sensor 2
 - Concentration of nitrate and, optionally, bisulfide
 - Support for all manufactured at MBARI
 - Some later models from Satlantic (in use at WHOI)
- TBD = Something new can yet be interfaced as RS-232 sensor 3
 - Note: this port is not currently wired to lid of the can



Polling Contextual Sensors

- Trickier than it would first seem
 - ISUS must synchronize with CTD to receive timely updates
 - Sample rate optionally quickens during sampling
 - Multiple threads may not access instruments simultaneously
 - The Can's internal sensor polling is controlled independently
- Code is in Polling object in [mission/skeleton.rb](#)
 - **Polling.start** #starts SensorPolling with new parameters
 - **Polling.stop** #stops polling and properly closes instrument files
 - **Polling.pause** #stops until resumed
 - **Polling.resume** #resumes previous polling schedule if paused
- **Instrument** shows last sampled state of all Instruments
 - **CTD, ISUS, Can** show last sampled state of each **Instrument**

Internal Environmental sensors

- **can** is short for **Sleepy.queryCan** --> forces immediate sampling
- **can.temperature** => internal temp. at top of can in degrees C
- **can.humidity** => humidity in % of saturation
- **can.pressure** => internal pressure in psia
- **can.voltage** => instantaneous battery voltage
- **can.current** => instantaneous battery load in amps
- **can.avgCurrent** => averaged battery load in amps
- **can.waterAlarm** => percent “wet” (0..100) usually < 1
- Wattage is merely **can.current * can.voltage**
- **Sleepy.can** accesses most recent sample
 - Typically updated every 10 minutes
 - Recorded in binary 'real.log' file
- **\$ dumplog @object.is Can** #will list Can environment samples
- **Sleepy.canPollInterval** = desired update rate for Sleepy.can
 - **Sleepy.canPollInterval = Delay.new “7:00”** #change rate
 - Set to zero to disable can environmental sampling entirely
 - Zero is the default for MFBs lacking Sleepy board.



Seabird CTD

- Seabird 16plus V2 CTD with
 - support for fluorometer, transmissometer, oxygen sensor, ...
 - Generates file `CTD-*.hex` of raw samples
- `CTD.status` # shows instrument status
- `CTD.pumpmode = mode`, where *mode* is either:
 - `:off`, `:beforeSample`, or `:duringSample`
- `s = CTD.sample` => returns sample object, assigns it to variable `s`
 - `s.temperature` => sea temperature in degrees C
 - `s.conductivity` => conductivity in S/m
 - `s.pressure` => pressure in decibars
 - `s.transmissometer` => % optical transmission
 - `s.beamAttenuation` => extinction coefficient in 1/m
 - `s.sampleTime` => time at which this sample was started
 - `s.dataTime` => time at which this sample was finished
 - `s.depth` => depth in meters (derived from pressure)
 - `s.salinity` => salinity in mythical PSUs
- More documentation in [lib/instrument/ctd.rb](#)



ISUS

- **ISUS** = In-Situ Ultraviolet Spectrometer
 - Stores raw spectra in **ISUS-*.dat** (MBARI's ISUS only!)
 - Logs errors in **ISUS-*.err**
 - **Requires temp., salinity & depth from the CTD !!**
- **ISUS.status** # shows instrument status
- **ISUS.species = 2** (or 3) #three to include bisulfide
- **ISUS.fit = 217..240** #spectral fit window in nm (tweak for species)
- **ISUS.fromCTD temp, salinity, depth** #update ISUS from CTD
- **s=ISUS.sample** => sample with most recent values fromCTD
 - **s.no3** => Nitrate concentration in uM/L
 - **s.br** => Bromide in uM/L
 - **s.hs** => Bisulfide in uM/L (only valid if species>2 and fit tweaked)
 - **s.sampleTime** => when sample was requested
 - **s.dataTime** => when sample was recorded
- More documentation in [lib/instrument/isus.rb](#)



Parameters controlling Contextual Sensor Polling

- *\$global* variables determine instruments' configuration/polling rates
- These may be assigned anytime before **Polling.start**
 - But, usually they get set once in [mission/phasecfg.rb](#)
 - Missions with **:until=>time** automatically invoke **Polling.start**
- CTD
 - **\$ctdPumpMode=:duringSample** #may be :beforeSample or :off
 - **\$ctdInterval=Delay.new "5:00"** #sample CTD every 5 minutes
 - **\$ctdPeriod=Delay.new "1:00:00"** #upload CTD data every hour
 - **\$samplingCTDinterval=Delay.new "2:30"** #2x faster ...
 - **\$samplingCTDperiod=Delay.new "30:00"** # while sampling
- ISUS
 - **\$isusSpecies = 2** #ignore sulfides by default (3 to include them)
 - **\$isusFit = 217.240** #because Luke says it should be so :-)
- ISUS polling rate is CTD sampling rate + 10 minutes
 - ISUS auto-sampling cannot be disabled

